

常用各种光藕(TOSHIBA\SHARP\FAILCHILD\NEC):



MOC3010	MOC3021	MOC3041	MOC3052	MOC3063
MOC3011	MOC3022	MOC3042	MOC3061	MOC3081
MOC3020	MOC3023	MOC3043	MOC3062	MOC3082
MOC3083	4N29A	4N35	4N38	6N137
4N25	4N30	4N36	6N135	6N138
4N26	4N32	4N37	6N136	6N139
4N27	4N33	TLP371	TLP559	TLP741G
4N28	TLP181	TLP372	TLP620	TLP2530
PC817	TLP180	TLP421	TLP621T	TLP3023
TLP112	TLP190B	TLP521-1	TLP621-4	TLP3042
TLP113	TLP191B	TLP521-2	TLP624-2	TLP3043
TLP115A	TLP260J	TLP521-4	TLP626	TLP3052
TLP116	TLP280	TLP250	TLP627-2	TLP3062
TLP127	TLP281-4	TLP251	TLP631	TLP3063
TLP126(F)	TLP331	TLP525G	TLP632	TLP3064
TLP130(GB)	TLP332	TLP525G-2	TLP701	TLP2200
TLP131	TLP350	TLP541G	TLP702	TLP2531
TLP137	TLP351	TLP550	TLP705	TLP2601
TLP141G	TLP360J	TLP557	TLP716	TLP2630
TLP160G	TLP361J	TLP558	TLP719	TLP2631
TLP168J	TLP504A	TLP504A-2	PS2501-1/2/4	PS2801-1/2/1